

INSTALLATION INSTRUCTIONS

1. Connect white wire to C3 on the tachograph.
2. Connect red wire to A3 on the tachograph.
3. Connect black wire to A5 on the tachograph.
4. Alternatively use the harnesses which may be provided in your kit.
5. Tacho Motion should be located such that it has a clear view of the sky through either glass or plastic. The unit's view of the sky should not be obstructed by metal.
6. On power up of the Tacho Motion check that the red LED is on, and then the LED changes to green permanently within 5 minutes before fixing in the vehicle.
7. The tachograph must be calibrated prior to the next operation.
8. Calibrate Tacho Motion using Optimo. Drive the vehicle and adjust the C3 speed factor so that speed 1 and speed 2 on the tachograph are within 10km/h of one another when the vehicle is traveling at 50km/h.
9. As a rule $C3 \text{ speed factor} = 8 \times I \text{ factor in metres}$

