


Změna tachografu SE5000 Rev.6 za Rev.7

vydaná dne: 8.1.2015

2015/01/2

Určeno pro interní potřebu AMS

Digital Application Sheet



VEHICLE MANUFACTURER	SCANIA
MODEL	ALL
YEAR OF MANUFACTURE	2005-on
ENGINE TYPE	DIESEL
TRANSMISSION	ALL
VOLTAGE	24V



STONERIDGE FITTING /PROGRAMMING INSTRUCTIONS TO REPLACE REV.6 SE5000 WITH REV.7 SE5000

TACHOGRAPH TYPE	ADR	NON-ADR
SE5000 TACHOGRAPH	5011SCA	5002SCA

INTRODUCTION

This is an instruction for installation of SE5000 Rev7 in Scania trucks and buses replacing older versions of SE5000 Rev6 of the tachograph.

When fitting the new Stoneridge, SE5000 R7 digital tachograph , a change in the cable connectors has to be done in order for the communication on the CAN bus to work fully.

FITTING INFORMATION

Step	Instruction	Comment
1	Move the vehicle cable connector, CAN H, from C5 on the tachograph to A4 on the tachograph.	
2	Move the vehicle cable connector, CAN L, from C7 on the tachograph to A8 on the tachograph.	The red C connector now has no function and can be removed from the tachograph.
3	Read all data with the MKII Programmer	
4	Go to Modify data and select parameter "CAN termination" and apply ON.	
5	Send the parameter together with other calibration parameters or press "send".	

CAN H z C5 na A4

CAN L z C7 na A8

Načíst data a ve změně dat nalézt a nastavit:

CAN omezení
: uvolnit

CAN termination – CAN omezení zapnout, čili uvolnit



zpracoval: Ing. Karel Jelínek

jelinek@stoneridge.cz GSM: 603 876 554